













DS-707




Sessel / Armchair






Sofa / Sofa






Hocker / Stool






Zwischenelement / Intermediate element






Eckelement links / Corner element left


















Eckelement rechts / Corner element right



Abschlusselement links / End element left



Abschlusselement rechts / End element right



/29 /45 /29

/30 /55 /30